



Cup washer

Bush

Flat washer Raised lip around centre hole
locates in chassis / axle bracket

Chassis / axle bracket

Flat washer

Bush

Cup washer

Nut